

Product information S7-Compact-PLC





(Figure contains optional periphery modules)



(valid from PLC-version CC307T-xxx-02)

Changes to older versions of this document

Rev. 01 \rightarrow 02: New design line, periphery modules added Rev. $02 \rightarrow 03$: Information for disposal of old equipment

Description

S7-Compact-PLC for 35mm DIN-rail with 7 periphery slots

Standard configuration:

RS232 with - free ASCII protocol

RS485 with

- free ASCII protocol
- Modbus RTU
- with switchable terminate resistors for RS485

2x Ethernet (as switch

- or separated) with - S7-connection (Put/Get) - Send/ Receive via
- TCP and UDP, - Modbus TCP
- Moubus I

CAN

- protocol compatible to
 CANopen[®]
- Layer2 communication - with switchable terminate
- resistors for RS485

Micro-SD-card slot - for SD-cards up to

8GByte

Run/Stop switch

State LEDs for Power, Battery, Error, Run

Inserting stripes - for Logo and identification (thereby customized adaption possible easy)

Additional configuration: (optional)

Profinet IO Controller


Scope of delivery: - Grounding terminal

- Technical data sheet



Figure above: View to rear side and connections sides of PC307T-PNC (horizontal use)

Figure below: CPU-connections of all Compact-PLC-devices with periphery slots with CPUs type T and with option Profinet IO Controller on slot 1









Technical data		
Dimensions W x H x D (mm) Cut out W x H (mm) Protection class Weight	161 x 116,5 x 98 35mm DIN rail IP41 ca. 600g	
Operating temperature range Storage temperature range	-20°C +60°C (without condensation) -30°C +80°C	
Connection technology	removable connector with 2 bolt flanges (cage clamp technology) for cross section up to max. 1,5mm ²	
Load voltage L+	24V DC (11 V 30V DC)	
Current consumption Power dissipation	150mA 1200mA 3,6W (typ.) 28,8W (mit Profinet and full of periphery)	
Start-up current	< 3A	
Technical data	CPU	
CPU-type	CPU-T (CC307T)	
Working memory / battery backed load memory Load memory	1MB / thereof 512 kByte remanent 8MB	
Diagnostic buffer	100 entries (all remanent)	
Flash external memory	Micro SD, up to max. 8 GByte (not necessary for S7-program, only for archiving)	
OB, FC, FB, DB Lokal data Number of in- and outputs Process image Number of Merkerbytes Number of Taktmerker Number of timer, counter Depth of nesting	each 2.048 32kByte (2kByte per block) in each case 4.096 Byte (32.769 Bit) addressable in each case 4.096 Byte (default set is 128 Byte) 4.096 (remanence adjustable, default set is 015) 8 (1 Merkerbyte) in each case 512 (each remanence adjustable, default set is 0) up to 16 code blocks	
Real-time clock elapsed hour counter	yes (accumulator-backed hardware clock) 1 (32Bit, resolution 1h)	
Program language Program system	STEP 7 [®] - AWL, KOP, FUP, S7-SCL, S7-Graph from Siemens SIMATIC [®] Manager from Siemens or products compatible to it	
Operating system Program unit to reference	compatible to S7-300 [®] from Siemens CPU 315-2DP/PN (6ES7 315-2EH14-0AB0 and firmware V3.1 Siemens)	
Serial interfaces (protocols)	COM1: RS 232 (free ASCII) COM2: RS 485 (free ASCII, Modbus-RTU)	
Ethernet (protocols)	2x Ethernet: (switch or separated ports): 10/100 MBit with parts of CP343 functionality (RFC1006, TCP, UDP, Modbus-TCP)	
CAN (protocols)	CAN-telegrams (Layer 2), compatible to CANopen [®] master/ slave 10 kBaud 1 MBaud	
optional interfaces (protocols)	Profinet IO Controller	
Onboard periphery	7 slots for INSEVIS-periphery modules (with Profinet-option slot 1 is occupied)	
Decentral periphery	 - INSEVIS- periphery (with automatic configuration via "ConfigStage") - diverse external periphery families (Modbus RTU/TCP, CAN) - all CANopen[®] slaves according to DS401 - all Profibus DP-V0-slaves 	



Ordering data of devices

Identification	Standard	With Profinet IO Controller
S7-Compact-PLC CC307T	CC307T-0-02	CC307T-PNC-02

Ordering data of accessoires (Peripheral modules to be ordered separately as required)			
Identification / Order-No.	Identification / Order-No.		
Connector 2x5pin (bolt flanges) / E-CONS10-00	Micro SD-card 2GB (external memory) / E-MSD2-00		
Micro SD-card 4GB (external memory) / E-MSD4-00	Micro SD-card 8GB (external memory) / E-MSD8-00		

Qualified personnel

All devices described in this manual may only be used, built up and operated together with this documentation. Installation, initiation and operation of these devices might only be done by instructed personnel with certified skills, who can prove their ability to install and initiate electrical and mechanical devices, systems and current circuits in a generally accepted and admitted standard.

Manuals, sample programs

Additional documentation by manuals is available as well sample applications at the download area of www.insevis.com in English language for free download.

Copyright

This and all other documentation and software, supplied or hosted on INISEVIS web sites to download are copyrighted. Any duplicating of these data in any way without express approval by INSEVIS GmbH is not permitted. All property and copy rights of theses documentation and software and every copy of it are reserved to INSEVIS GmbH.

Trade Marks

INSEVIS refers that all trade marks of particular companies used in own documentation are reserved trade marks are property of the particular owners and are subjected to common protection of trade marks.

Disclaimer

All technical details in this documentation were created by INSEVIS with highest diligence. Anyhow mistakes could not be excluded, so no responsibility is taken by INSEVIS for the complete correctness of this information. This documentation will reviewed regularly and necessary corrections will be done in next version. With publication of this data all other versions are no longer valid.

Disposal

Do not throw old appliances in the household waste! In the interest of environmental protection, old appliances must be collected separately from unsorted municipal waste. You can find out more about the proper disposal / return of your old appliance at <u>www.insevis.com/disposal</u>. Attention: The deletion of personal data on the old devices to be disposed of is the responsibility of the end user.

With publication of this information all other versions are no longer valid.